

Freightliner
Century Class (COB) 2008
Mounting Instructions

Step 1: Remove Factory Bumper



Factory Bumper Shown

Step 2: Remove bolts & brkt



Frame Mounting shown



Frame shown w/bracket removed



Step 3: Install Brackets (psgr side shown)



Step 4: After bumper is installed, mount
Bumper End Support Bracket



Complete mounting shown

Step 5: Install Premium Chrome Bumper



Chrome Replacement Shown