

# ***CY Mounting Instructions***

## ***2009 Freightliner Cascadia***

***\*Please use the included bolts and hardware.***

***Front***

***Frame View***

***1***



***2***



***Bolt mounting brackets to bottom of frame.***

***Adjust angle of brackets for best fit.***

***Top***

***Rear***

***3***



***Mount the top extension panels to bumper.***

***4***



***Attach provided mounting bracket to ear of bumper***



***Check all mounting points and adjust as necessary.***

***800-354-0976 [www.valleychrome.com](http://www.valleychrome.com)***